

PRODUCT INFO



*Please scan
the QR-Code
to get the
digital
product info
data sheet.*



RC plus⁺

REMOTE CONTROL



PRODUCT INFO



RC plus⁺ Remote control

The RCplus+ has 2 operation levels: Test- & welding mode (working mode)

OPERATING OPTIONS //

- Start & Stop
- Weld without electric arc – test run
- Turn left and right
- Wire back and forward
- Adjustment of OSC & AVC - axes
- Modification of oscillation width also while welding
- Modifications of the currents and wire speeds also while welding

Thanks to a built in, internal LED-light, the operating condition “welding” is indicated by flashing of the LED. If you are in the modification-mode while welding, the flashing phase ON is longer than OFF (optical identification if modifications are locked or free).

In case of a fault indication, it flashes in the same binary like the signal of the welding machine.

In addition the RCplus+ is upgradeable with the wireless remote control “RCplus+ wireless” to enable a wireless control of the welding up to 30 m guaranteed distance.

Advantage: applicable on each welding system as there is no internal communication, but this is regulated between both remote controls.

DATA //

Weight (kg)	1,8 (incl. cable)
Dimensions (L x W x H)	120 mm x 70 mm x 30 mm

